

DISHWASH LIQUID

Dishwasher Detergent Liquid



Our highly active, low foaming dishwasher detergent can be used in all types of automatic dishwashing machines.

Designed for the professional caterer, our specially formulated dishwashing detergent removes all types of food soiling from crockery, cutlery and stainless steel and prevents soil and limescale from being redeposited, removes staining and ensures crockery is thoroughly clean.

- Low foaming
- Removes and prevents limescale and soil build up from all types of kitchen utensils
- For use in all types of automatic dishwash machines
- Suitable for hard water areas
- Can be used in conjunction with Dishwash Rinse Aid



APPLICATIONS

Do not use for hand dishwashing. Contains sodium hydroxide: avoid contact with skin.

For best results, use in conjunction with Dishwash Rinse Aid.

PACKAGING

Order Code: AP252

Pack Size: 2 x 5L

DIRECTIONS

Dishwash Liquid is ideally best dispensed into an automatic dishwashing machine through an electronic dispenser at a ratio of 1-3ml per litre, depending on amount of soiling and the hardness of the water, or in accordance with the dishwasher machine manufacturer's instructions.

STORAGE

For best results, store in the original container, in cool dry conditions away from direct sunlight.

Keep out of the reach of children.



BIO PRODUCTIONS LTD

72 Victoria Road, Burgess Hill, W Sussex, RH15 9LH

T: 0044 1444 244000 | F: 0044 1444 244999

E: sales@bio-productions.com

W: www.bio-productions.com